


Driver Card

To properly start using the Fortune ELD, complete the following:

- Sign in to the application with your account credentials.
- Connect the device to a reliable power source inside your vehicle.
- Install the device securely on the dashboard to ensure proper functionality.


1. **Additional Menu** icon.
2. **Malfunctions and data inconsistencies** icon shows if there are any issues with a track or ELD.
3. **Truck** icon shows track to PT30 connection.
4. **Flag** icon shows the rules of which country you are following at the moment.
5. **Current status.**
6. **HOS counter.**
7. **Co-driver** icon allows to switch a driver.
8. **Name** icon shows the name of the driver whose working hours are counting at the moment.



Fortune ELD is compliant with the Federal Motor Carrier Safety Regulations CFR §395.15 and 49 CFR 395.20 et seq. Fortune ELD is compliant with Section 83 of. The Commercial Vehicle Drivers Hours of Service. Regulations regarding the use of electronic logging devices.

DOT Inspection

The DOT Inspection menu summarizes all the collected data about the driver, truck, and trip. You can also use this menu to transfer the data to FMCSA during the DOT inspection, certify your logs, or view unidentified records.



To begin the inspection, tap the **Start Inspection** button and check if your logs are ready to be transferred to the safety officials.

Data Transfer

If everything is OK, tap the **Transfer Data to Police** button and choose the method of sending your logs:

- **Send it to the Web Services (FMCSA)**
- **Send it to the FMCSA email**

You need to add a comment and tap the “Send CSV” button to complete the Data Transfer.

The reporting period will vary depending on the rules of the country in which you operate.

Also you can choose “Send it to the personal email”. You need to enter the recipient’s address, add a comment (optional) and tap the “Send PDF” button .

